500a fuse for SAM's starter jumper

BST-FUSE...

SAM Outillage
10 rue Camille de Rochetaillée
42000 Saint-Etienne - France
RCS Saint-Etienne B 338 002 231 | SAS au capital de 8 189 583 €
https://www.sam-outillage.com/

Photos and texts not contractually binding. Do not litter. Document generated on 2024-05-06 21:37:46

AUTOMOTIVE

DESCRIPTION

500a fuse for SAM's starter jumper

Spare part for starter booster BST- 12A and BST- 12- 24A.

BST-FUSE : fuse in the body of the starter booster.

BST-FUSE2 : fuse located under the sheath of the red clamp of the starter booster.

SPECIFIC DATA

Sales reference	Weight (kg)	Guarantee
BST-FUSE	0.018	C
BST-FUSE2	0.018	C

AUTOMOTIVE

Guarantee applied

C | Consumable

The products in this category will not be replaced and are subject to normal wear phenomena.

>> Find out more